

VACUUM CONTROLLER

Quick start guide

R-VAC-1

- Make sure your pressure/vacuum switch is set to the middle position.
- Make sure your pressure regulator is fully closed by pulling the knob up and rotating it counter-clockwise as far as it will turn.
- Connect your hose from the compressor to the vacuum controller inlet on the right side of the controller. (Male air connector on the first picture)
- Connect your outlet hose to the vacuum controller outlet on the left side of the controller. (Female air connector on the second picture)
- Turn the pressure on by moving the switch to the "Pressure" side.
- Adjust the desired pressure by pulling the regulator knob up and rotating it clockwise.
- To switch on the vacuum mode, turn the switch on the "Vacuum" side.

Remember, the vacuum airflow cannot be adjusted with the regulator!



RENSSI®
DRAIN CLEANING EQUIPMENT

Renssi Finland Oy
Jousitie 6, 20760 Kaarina FINLAND
info@renssi.com
www.renssi.com